



TECHNICAL DATA:

NOMINAL OPERATING VOLTAGE 160KV DC
- USING AN ESSEX X-RAY APPROVED RECEPTACLE
CABLE LENGTH TOLERANCE $\pm 100\text{mm}$

CABLE:- VOLTAGE WITHSTAND 160KV DC
50KV (RMS) AC Δ 2

FOR FULL CABLE DATA SEE ESSEX CABLE DATA SHEET

ACCESSORIES:

FLANGE T21417

INSTALLATION GREASE P00075

INSTALLATION:

CABLE SHOULD ONLY BE FITTED BY A TRAINED PERSON.
OIL MUST NOT BE USED ON THE RUBBER TERMINATION, ONLY SUITABLE
HIGH VOLTAGE GREASE.
ENSURE BY ADJUSTING THE CLAMPING SLEEVE THAT WHEN THE
TERMINATION IS FULLY INSERTED IN THE SOCKET THERE IS A
GAP OF 6mm BETWEEN THE MATING FACES OF THE CLAMPING SLEEVE
AND SOCKET BEFORE TIGHTENING THE CLAMPING SLEEVE.



REVISONS			DUE TO CONTINUING PRODUCT DEVELOPMENT ESSEX X-RAY RESERVES THE RIGHT TO MODIFY DATA WITHOUT NOTICE					
NO.	DATE	BY	DRAWN MGM	APPROVED	DATE 07.02.03	ISSUE 2	SCALE N.T.S.	© NOT TO BE REPRODUCED IN WHOLE OR PART WITHOUT PRIOR PERMISSION OF ESSEX X-RAY & MEDICAL EQUIPMENT LTD.
2	09.03.09	DCN 2905						
			TITLE PANTAK TERMINATIONS NEW STYLE FERRULE (CABLE TYPE C2042)					DRAWING No. DS1067

DRAWING No.	DS1067
-------------	--------